

WR/023 Fold-away Supreme (P) & WR/023-1 Fold-away Supreme (G)

10 Lines

STRINGING

- Start at the front cleat and tie line with a double knot.
- Extend the line to opposite cleat, pull taught, wrap it around cleat once and move to next cleat on the same arm.
- Hook line around cleat and extend to the opposite cleat. Repeat

STRINGING DIAGRAM

