

RETRACT-A-LINE - INDOOR

WL/003

INSTALLATION / OPERATING INSTRUCTIONS

INSTALLATION

- Find a suitable position to install your RETRACT-A-LINE INDOOR
- You require a minimum area of 0.6m x 4.2m for RETRACT-A-LINE model WL/003 - 4 lines by 4.2 meters. Do not exceed 4.2meters.
- In addition to the above, is it recommended that you leave 0.6m on at least one side over the full length to allow free access to the laundry.
- The ideal height is between 1.6 – 1.8 meters.
- Refer to the Minimum / Recommended Area Requirements schematic drawings

CABINET

- Determine the position for your RETRACT-A-LINE INDOOR.
- Note the fixing hole on the side of the box or refer to the Mounting Holes schematic drawings.
- Measure and mark the cabinet holes.
- Drill the holes with a 7mm masonry drill and hammer in the plugs.
- Fix the holding bracket with the 35mm screw.
- Make sure the tensioning knob is facing outwards for easy access.
- Hook the cabinet onto the bracket (turning knob side)
- Fix the other end of the cabinet with the 60mm screw.
- NB! Do not over-tighten as this could crack the cabinet.

HOOKS

- The hooks must be directly opposite the cabinet, at the same height as cabinet as well as in the center of the cabinet.
- Note the fixing hole on the side of the box or refer to the Mounting Holes schematic drawings.
- Measure and mark the hook holes.
- Drill the holes with a 7mm masonry drill and hammer in the plugs.
- Screw the hooks in at the same depth and end up with the hooks pointing upwards.

OPERATION

EXTENDING

- Disengage the lock by pulling the tensioning knob outwards.
- Pull the line bar out towards the opposite wall, turn 90 degrees and hook into position. **NB!** Ensure that it is hooked properly.
- Turn the tensioning knob anti clock wise until all the lines are tight.
- Push the tensioning knob in to lock the lines.

RETRACTING

- Remove all the laundry from the line - including pegs.

- Disengage the lock by pulling the tensioning knob outwards.
- Unhook the line bar and return controlled and straight to the cabinet.

CARE

- Always return the pull-bar to the cabinet after use.
- Do not overload. Load rated at 10Kg evenly distributed.

WARNING

- **THE UNIT IS FACTORY ASSEMBLED AND UNDER HIGH TENSION**
- **DO NOT** allow the pull-bar to return un-controlled – it **WILL** result in personal injury and damage to the unit.
- Wear eye protection during installation.
- **DO NOT** allow children to play / swing / hang on the lines, as this **WILL** result in personal injury and damage to the unit.
- **DO NOT** tamper with the unit as this **WILL** result in personal injury and damage to the unit.
- During strong winds, remove your washing to prevent damage to the unit.
- **NB! STRANGULATION DANGERS**

RESTRINGING

WARNING

Do not attempt to do this alone as the spring will be under tension and uncontrolled release could result in bodily harm.

This operation may only be performed by a competent person and should not be performed by a minor.

This operation requires at least 2 persons, do not attempt this alone.

Remove the unit from the wall.

TENSIONING THE CABINET

- Make sure that the spring is fully unwound.
- Remove all of the old string.
- Pull the locking knob outwards and wind the spring up in a clockwise direction for 34 full revolutions and push the locking knob into the locked position. – **NB! Make sure that it is properly engaged and the drum locked.**
- **As a safety precaution tape the knob fixed to the drum to prevent accidental un-locking.**
- Make sure that the ridge on the drum is at the back.
- Place the cabinet with the knob on the right-hand side and the open end facing backwards – away from you.

PLACING THE PULL BAR

- Placed the pull bar opposite the cabinet approximately 5 meters away.
- Ensure that the back is facing upwards and the stinging holes facing the cabinet.

CUTTING THE STRING

- The string specifications are; 2 millimeter in diameter and 21.6 meters in length – NB! Do not use a thicker string as this will prevent the string to equalize. NB! Do not use a longer string as this will prevent the Pull Bar to retract fully.

STRINGING

- Start at the left side of the pull bar.
- Pull the end of the string through the two holes, in the “U” shaped part and make a knot.
- Take the other end and feed it through the left hole in the cabinet and out the back of the cabinet underneath the drum.
- Feed the string in through the first hole on the ridge on the drum and out through the second.
- Feed the string under the drum out through the hole in the cabinet back to the pull bar.
- At the pull bar feed the string in through the second hole and out through the third hole.
- Repeat operation till all lines are strung.
- Tie the end of the line back in the drum at the knob side in the space provided.

REWINDING

- Take hold of the cabinet and the pull bar, one person at each side.
- Gently walk apart as far as possible.
- Gently feed the line fro and back until all lines are of equal length.
- Remove the security tape from the drum and unlock.
- Gently move towards each other to rewind the string – repeat this 2 or 3 times to ensure that it operates smoothly.
- Replace the cabinet on the wall.

GUARANTEE

Please refer to the Product Guarantee Policy on the Website at www.star-line.co.za

Copy right rest in NA Manufacturing (Pty) Ltd

