

FOLD-AWAY SUPREME

WR/023 POWDER COATED
WR/023-1 GALVANIZED

INSTALLATION / OPERATING INSTRUCTIONS

LOCATION

- Find a suitable position to install your Fold-away Rack.
- You require a minimum area of 1.44m deep (front to back) by 1.8m wide (left to right) for the Fold-away Ultimate.
- In addition to the above, it is recommended that you leave 0.6m all around to allow free access to the laundry.
- Refer to the Minimum / Recommended Area Requirements schematic drawings.
- The ideal height is between 1.6 – 1.8 meters.

INSTALLATION

- Note the hole fixing diagram on the instruction insert or refer to the Minimum / Recommended Area Requirements schematic drawings on the web site / packaging.
- Accurately mark the holes on the wall, ensure that they are level.
- Drill the holes with an 8mm masonry drill.
- Ensure that you drill the holes into solid brick and not a hollow-core brick or mortar as this will reduce the holding capacity of the anchor fasteners.
- Hammer the wall plugs in.
- Fix both arm assemblies to the wall by using the coach bolts and washers supplied.
- Join the spacer bar together and insert the reduced ends into the open ends of the arms.
- Secure the spacer bar with the fasteners provided.

RE-STRINGING

- Refer to the stringing diagram on the web site / packaging
- Remove all the old and worn-out string.
- NB! Use only original STARLINE Silver Replacement Line, reference code NPS/SL-35, or STARLINE Silk Steel Replacement Line, reference code NPS/SSCL-35 if a stronger line is required. You require approximately 26 meters of line.

STRINGING

- Start at the front cleat and tie a double knot.
- Extend the line to the opposite cleat, pull taught, wrap it around the cleat once and move to the next cleat on the same arm and wrap the line around the cleat.
- Extend the line to the opposite cleat.
- Repeat until completely strung and tie the end off.

OPERATION

- Take hold of the spacer bar in the center and open it outwards and upwards.
- Swivel the gusset tube upwards and engage the bracket into the tube end.

- Repeat on the other side.
- To fold down, lift the rack upwards allowing the gusset tubes to drop down.
- Lower the rack gently downwards against the wall.
- NB! Do not attempt to lower the rack whilst loaded with washing as it could twist resulting in damage.

CARE

- Always wipe the line clean before you hang your laundry.
- Load rating is 40Kg evenly distributed, do not overload / shock load.

WARNINGS

- Wear eye protection during installation.
- **Do not** allow children to swing or climb on the washing pole as this can result in personal injury or breakage.
- **Do not** subject the arms to shock loads as this can result in personal injury or breakage.
- During high winds remove your laundry to prevent damage/loss.
- **NB! STANGULATION DANGERS**

GUARANTEE

Please refer to the Product Guarantee Policy on the Website at www.star-line.co.za

Copy right rest in NA Manufacturing (Pty) Ltd