

WL/001 3x5 Retract-a-Line

3 Lines

RESTRINGING

NB! THIS IS AN EXTREMELY DANGEROUS OPERATION AND MUST BE DONE BY TWO COMPETENT PERSONS.

NB! READ THESE INSTRUCTIONS CAREFULLY AND UNDERSTAND WHAT YOU MUST DO BEFORE ATTEMPTING TO DO SO.

- **NB! Extreme care must be taken as this could result in personal injury to you or bystanders and could damage the unit.**
- **NB! When performing this operation prevent children / pets from accidentally distracting you which could lead to personal injuries.**
- **Remove the pull-bar from the cabinet and pull it away until completely unwound.**
- **Make sure that the tying eyes on the drum are visible through the opening and facing the front.**
- **Secure the pull-bar positively to a fixed stationary object.**
- **Engage the locking lever (red lever) to prevent re-winding.**
- **NB! Replace one line at a time only.**
- **Untie the line from the pull-bar and cut the knot at the drum end.**
- **NB! Use only original STARLINE SILK STEEL REPLACEMENT LINE , reference code NPS/SSCL-35 for the 3 line unit.**
- **Cut the replacement line into 3 lengths of 5.2 meters.**
- **Feed the end of the line through the eye, from the top, and make a “figure eight knot” on the line and pull tight.**
- **Feed the other end through the cleat on the pull-bar and lock into position.**
- **Repeat this with all the other lines.**
- **Carefully disengage the locking lever (red lever).**
- **Release the pull-bar from the secure position.**
- **Return the pull-bar in a controlled manner.**
- **Draw the pull-bar up to its normal operating position and back a few times to ensure that it is operating smoothly.**

RESTRINGING DIAGRAM

